


PLUG it in  
& PLAY


TV  
GAMES

# STAR WARS

## REVENGE OF THE SITH



Open battery door with a screw driver.  
Insert 4 new AA/R6P batteries following  
polarity indicated & close battery door.  
Alkaline batteries are recommended.  
Batteries should be replaced by an adult.



If you  
experience  
screen problems such  
as ghosting or fading,  
batteries may need  
to be changed.

If you  
experience further  
difficulties, restart  
the controller by  
powering OFF then  
ON again.

When operating in environments that  
are subject to electrostatic discharges  
the game may malfunction and scores  
may be lost. If this occurs, the user  
should reset the game by using the  
on/off switch.

### WARNING

- do not mix old and new batteries
- do not use rechargeable batteries
- never mix alkaline, standard (Carbon-Zinc) and rechargeable (Nickel-Cadmium) batteries
- only batteries of the same or equivalent type as recommended are to be used
- batteries are to be inserted with correct polarity
- exhausted batteries are to be removed from the toys
- the supply terminals are not to be short-circuited
- different types of batteries or new and used batteries are not to be mixed
- non-rechargeable batteries are not to be recharged

### INSTALLATION

1. Install batteries
2. Connect the TV Game unit to TV or VCR. Plug the yellow input into Video IN yellow port & the white input into Audio IN white port on your TV or VCR.
3. Turn on the TV Game unit. Turn on TV and/or VCR and select the appropriate "Line-in" source. Refer to your TV/VCR manual for more information. If your TV does not have Audio or Video input but has a SCART socket, you will need to purchase a AV/SCART adapter from most major electronic stores to operate this product

*Join the Jedi and TV Games to defeat the dark side in  
5 Star Wars: Revenge of the Sith adventure games. May  
the Force be with you as you ride, fly, and lightsaber to  
protect the Republic and defeat the Separatist invasions!*

### Getting Started

After turning on your TV Games and viewing Credit screens, Star Wars Main Menu appears. **D-Pad** left/right to scroll through the 5 available games and press **A button** to select one. View the game instructions and press **A button** to enter game or **B button** to return to Main Menu.

### Pause Screen


Press **Pause** during game play to pause. Press **A button** to select 'Continue' and resume play or select 'Main Menu' to quit current game and return to the Main Menu.

3+  
TM

www.pegli.info



## Gunship Battle



It's clone against clone...Fly above the field in your Republic gunship, deploying troopers for battle and helping them advance! Place your clones at fueling bases and gun turrets for takeovers, shoot down enemy gunships, and get four clones inside the Separatist base for a momentous victory!

### Controls

**D-Pad:** Move gunship

**A button:** Fire primary weapons

**B button:** Drop proton bomb

## Grievous Onslaught

Use the Force and Anakin's lightsaber to rescue Chancellor Palpatine. Aboard General Grievous' flagship, you must battle merciless droids to access more rooms and avoid Grievous who closely follows. Grab Power-Ups that shield, stun enemies, or push foes on your way to the main bridge. Defeat the bodyguards and free Palpatine!

### Controls

**D-Pad:** Move in 8 directions

**A button:** Swing lightsaber/deflect blasts


**B button:** Activate stored Power-Up





# Coruscant Attack

Fly Obi-Wan into action at Coruscant. Repel waves of droid control ships in your Jedi starfighter and destroy Separatist battleships by shooting down their gun turrets and missile launchers. Grab as many Power-Ups as possible for upgraded blasters, mines, the ability to slow time, and Anakin Skywalker's help... Save Coruscant and stop the invasion!



## Controls

**D-Pad:** Rotate ship

**A button:** Fire weapons

**B button+D-Pad:** Drift in a single direction & rotate ship

## Droid Invasion


Stand your ground as Obi-Wan deflects the Separatist droid invasion! Ricochet their blaster attacks to score big with hits and destroy them all, but be prepared for large Separatist vehicles with guards that are harder to destroy. Pick Power-Ups from defeated droids that shield Obi-Wan, give him a double-bladed lightsaber, an extra life, or the ability to push enemy lines using the Force.

## Controls

**D-Pad:** Move left/right


**A button:** Deflect blasts

**B button:** Activate current Power-Up





## Utapau Chase



General Grievous has been tracked down on the planet Utapau! Guide Obi-Wan on Boga through gun turret fire and colliding enemy speeders. Chase down the General's speeder for an all-out battle and end the Separatist threat once and for all. Grab Power-Ups that upgrade blasters, armor your Boga, or give extra lives.

### Controls

**D-Pad:** Move in 8 directions

**A button:** Fire weapons

**B button:** Swing tail

©2005 JAKKS Pacific, Inc., Malibu, CA 90265. All Rights Reserved. The Plug It In And Play TV Games™ logo, the jakkstvgames.com™ logo and the JAKKS Pacific® logo are trademarks of JAKKS Pacific, Inc.

©2005 Lucasfilm Ltd. & TM. All rights reserved.

Developed by Amaze. ©2005 Amaze Entertainment, Inc. Amaze Entertainment and the Amaze Entertainment/Griptonite logo are trademarks or registered trademarks of Amaze Entertainment in the United States and/or other countries.

All other trademarks and trade names are the properties of their respective owners. MADE IN CHINA.

Please retain this instruction for future reference.

When operating in environments that are subject to electrostatic discharges, the game may malfunction and scores may be lost. If this occurs, the user should power OFF then ON again the game.

JAKKS Pacific

jakksTVgames.com

GRIPTONITE  
GAMES  
AN AMAZE ENTERTAINMENT STUDIO



3+  
TM

www.pegi.info